

Electronic Services - Hayward, Ca



INSTRUCTION MANUAL



**RETURN TO A277  
CALIBRATION LAB.**

**TYPE 1330-A**

**BRIDGE OSCILLATOR**

GENERAL RADIO COMPANY

1330-A

INSTRUCTION MANUAL

TYPE **1330-A**  
BRIDGE OSCILLATOR

Form 1330-0100-J  
ID-B545  
March, 1968

GENERAL RADIO COMPANY  
WEST CONCORD, MASSACHUSETTS, USA

# TABLE OF CONTENTS

	Page
Section 1. INTRODUCTION . . . . .	1
1.1 Purpose . . . . .	1
1.2 Description . . . . .	1
Section 2. PRINCIPLES OF OPERATION . . . . .	2
2.1 R-F Oscillator . . . . .	2
2.2 Audio Oscillator and Modulator . . . . .	2
2.3 Output Characteristics . . . . .	2
Section 3. OPERATING PROCEDURE . . . . .	2
3.1 Installation . . . . .	3
3.2 Control Settings . . . . .	3
Section 4. SERVICE AND MAINTENANCE . . . . .	3
4.1 Warranty . . . . .	3
4.2 Service . . . . .	3
4.3 R-F Section . . . . .	4
4.4 Calibration Procedure . . . . .	5
4.5 Test Voltages . . . . .	7




Figure 1. Type 1330-A Bridge Oscillator.

# TYPE 1330-A BRIDGE OSCILLATOR

## Section 1 INTRODUCTION

1.1 PURPOSE. The Type 1330-A Bridge Oscillator (Figure 1) is a stable, variable-frequency power source for bridge and other measurements at audio and radio frequencies. It supplies three fixed audio frequencies (power-line frequency, 400 and 1000 cps) and a continuous range of radio frequencies from 5 kc to 50 Mc, with a power output high enough for most laboratory measurements.

### 1.2 DESCRIPTION.

1.2.1 GENERAL. The Bridge Oscillator is housed in an aluminum cabinet, which can be removed for relay-rack mounting. To reduce leakage and stray fields, the radio- and audio-frequency circuits are enclosed in a completely shielded compartment within the main cabinet. The two leads for plate and heater power are carefully filtered. The shafts that extend from the compartment through the panel are shielded by the grounding of the knob inserts that enclose the shafts. The cover of the r-f compartment is of double construction with spring contacts bearing on both the inside and outside walls of the compartment.

1.2.2 CONTROLS. The following controls are on the panel of the Bridge Oscillator:

<u>Name</u>	<u>Type</u>	<u>Function</u>
POWER	2-pos toggle switch	Energizes instrument.
RF RANGE	8-pos selector switch	Selects any of 8 r-f ranges.
None	Continuous rotary control with slow-motion dial	Main frequency control.
RF-AUDIO	6-pos selector switch	Determines mode of operation (refer to paragraph 3.2.1).
% MOD	2-pos toggle switch	Selects either 25% (LOW) or 50% (HIGH) modulation.
RF CONTROL	Continuous rotary control	Controls r-f output power.

1.2.3 CONNECTIONS. The following connections are on the panel of the Bridge Oscillator:

<u>Name</u>	<u>Type</u>	<u>Function</u>
AUDIO	Type 874 Locking Coaxial Connector and jack-top binding post (ground)	Audio output connection.
RF	Type 874 Locking Coaxial Connector and jack-top binding post (ground)	R-f output connection.

1.2.4 ACCESSORIES. The following accessories are supplied with the Bridge Oscillator:

<u>Item</u>	<u>Qty</u>	<u>Part No.</u>
Adjustment wrench (mounted on oscillator cover)	1	TO-44
Power Cord	1	CAP-22
Coaxial patch cord	1	874-R22L <sup>A</sup>
Adaptor	1	874-Q2
0.50-amp Slo-Blo fuse (for 115-v)	2	5330-1000
0.25-amp Slo-Blo fuse (for 230-v)	2	5330-0700

## Section 2

### PRINCIPLES OF OPERATION

**2.1 R-F OSCILLATOR.** A Hartley-type r-f oscillator is used in the instrument. The r-f frequency range is determined by the setting of a turret which carries the eight coils and some associated components. To obtain a compact turret assembly, the coils are mounted alternately on either side of a disc that carries 48 contacts. Each of the eight ranges covers a frequency ratio of 3.33 to one (4.8 to 16 and 15 to 50).

The capacitance change of the main tuning capacitor (C1) is about 750  $\mu\text{f}$ . The plates are especially shaped to yield a logarithmic frequency calibration. The 15-50 Mc range does not use the entire capacitance span of the main tuning capacitor. The calibration for this range is not logarithmic, and the "percent frequency change" calibration on the slow-motion dial does not apply.

The voltage at the load is controlled by the RF CONTROL voltage divider. When this control is set for full output, load variations may affect the frequency. Maximum power output is obtained with a load of about 50 ohms.

With the RF-AUDIO switch at AUDIO, the r-f oscillator cathode circuit is opened, and the r-f oscillator does not function.

**2.2 AUDIO OSCILLATOR AND MODULATOR.** The tuned-plate-type audio oscillator uses a 6AQ5 miniature beam-power tube, with the 0.25- $\mu\text{f}$  r-f oscillator plate-supply bypass capacitor serving as audio-oscillator tuning capacitor. The frequency of the audio oscillator can be either 400 or 1000 cycles. The inductor of the audio tuned circuit is tapped to change frequency, and additional capacitance (C8) is switched in for 400-cycle operation.

The heaters of the two oscillator tubes are connected in series, and the total heater-winding

voltage (12.6 volts) is brought out at the AUDIO jack when the RF-AUDIO switch is in the LINE position.

The AUDIO jack is coupled directly to the audio oscillator or through a 51-ohm resistor to the heater winding. There is no provision for controlling the audio amplitude.

When the RF-AUDIO switch is in either of the MOD positions, the full swing of the audio oscillator is applied to plate-modulate and screen-modulate the r-f oscillator. The depth of modulation is about 25 percent with the % MOD switch at LOW, about 50% with the switch at HIGH, for both MOD settings of the RF-AUDIO switch.

When the RF-AUDIO switch is at one of the AUDIO positions, the plate supply is loaded by the audio oscillator tube V2 and by the resistance load R4. When the switch is at one of the R-F positions, the plate supply is loaded by the r-f oscillator and by the audio oscillator tube.

**2.3 OUTPUT CHARACTERISTICS.** Output characteristics of the Bridge Oscillator are as shown in Figure 2.




Figure 2. Typical Output Characteristics of Bridge Oscillator.

## Section 3

### OPERATING PROCEDURE

#### 3.1 INSTALLATION.

**3.1.1 POWER INPUT.** Connect the Bridge Oscillator to a source of power as specified on the plate near the power input receptacle. Power-line frequency is 40 to 60 cycles, and voltage is either 115 or 230

volts. If you desire to change from one input voltage to the other, change the power-transformer connections as shown in Figure 4, reverse the plate near the power input receptacle, and replace the fuses (at the rear of the cabinet) with those of proper rating (refer to paragraph 1.2.4). For access to power-

transformer connections, remove the instrument from the cabinet and remove the left side shield, attached by three screws.

3.1.2 OUTPUT CONNECTIONS. If shielded connections are not required (e.g. at lower frequencies), you can plug the Type 874-Q2 Adaptor into either the RF or AUDIO panel connection. Similarly, a Type 274-MB Plug can be inserted into either output connector and its associated ground terminal.

At higher frequencies, a shielded output cable should be used. The Type 874-R22LA 50-ohm coaxial patch cord can be plugged directly into either output jack. A comprehensive line of low-leakage plug or jack type coaxial adaptors, from GR874 to other leading 50-ohm connector series, are available, if required.

Proper cable termination is important only at frequencies above the broadcast band and only if it is desirable to avoid standing waves and hence variations in output voltage with frequency. With the RF CONTROL set for full output (fully clockwise), the 50-ohm patch cord is approximately terminated at the oscillator end.

### 3.2 CONTROL SETTINGS.

3.2.1 MODE SELECTION. Set the RF-AUDIO switch to the desired mode of operation. There are three r-f positions for operation from 5 kc to 50 Mc, either unmodulated (CW) or modulated (MOD). The modulating frequency can be either 400 or 1000 cycles.

### CAUTION

Do not use either MOD position if the operating frequency is to be in the 5-15-kc range. With modulation, the r-f voltage across the tuning capacitor may be high enough to arc over. This is most likely at high modulation levels and at high line voltages.

There are three audio positions for operation at either the line frequency, 400 cycles, or 1000 cycles. The amplitude of the audio output voltage at the AUDIO output jack cannot be adjusted. Output impedance at the AUDIO jack is about 50 ohms.

3.2.2 PERCENT MODULATION. With the % MOD toggle switch at LOW, the degree of modulation is about 25 percent; at HIGH, about 50 percent. There are no provisions for external modulation.

3.2.3 FREQUENCY CONTROLS. The two radio-frequency controls are the RF RANGE switch and the frequency tuning dial. Set the RF RANGE switch to the desired frequency range (refer to CAUTION in paragraph 3.2.1) and set the frequency tuning dial to the desired frequency. Use that portion of the large dial corresponding in color to the RF RANGE switch position used. Note that the 15-50 Mc position of the RF RANGE switch is identified by a double line, corresponding to the inner scale on the frequency tuning dial.

The smaller frequency-tuning dial is calibrated to indicate directly small percentage increments in frequency. Each division of this dial corresponds to a 0.1-percent change in frequency except at the ends of the main frequency dial.

## Section 4 SERVICE AND MAINTENANCE

### 4.1 WARRANTY.

We warrant that each new instrument sold by us is free from defects in material and workmanship, and that, properly used, it will perform in full accordance with applicable specifications for a period of two years after original shipment. Any instrument or component that is found within the two-year period not to meet these standards after examina-

tion by our factory, district office, or authorized repair agency personnel, will be repaired, or, at our option, replaced without charge, except for tubes or batteries that have given normal service.

### 4.2 SERVICE.

The two-year warranty stated above attests the quality of materials and workmanship in our pro-

ducts. When difficulties do occur, our service engineers will assist in any way possible. If the difficulty cannot be eliminated by use of the following service instructions, please write or phone our Service Department (see rear cover), giving full information of the trouble and of steps taken to remedy it. Be sure to mention the serial and type numbers of the instrument.

Before returning an instrument to General Radio for service, please write to our Service Department or nearest district office, requesting a Returned Material Tag. Use of this tag will ensure proper handling and identification. For instruments not covered by the warranty, a purchase order should be forwarded to avoid unnecessary delay.

#### 4.3 R-F SECTION.

4.3.1 REMOVAL PROCEDURE. All tubes and many components can be serviced without removal of the r-f section from its compartment. If it does become necessary to remove this section, proceed as follows, being careful not to lose the various spring washers, spacers, phenolic sleeves, etc., since they provide the means for shielding the shafts and grounding the knob inserts:

a. Remove the 10 slotted thumb screws along the edges of the front panel and pull the instrument out of the cabinet.

b. Remove the two black-nickled screws that attach the cover plate of the main tuning dial to the panel. This allows removal of the cover plate, and with it the slow-motion dial assembly.

c. Remove the main tuning dial index assembly, which consists of two No. 4-40 screws, two plain washers, two lock washers, two 11/32 spacers and the plastic index.

d. Remove the RF RANGE switch knob after loosening its two setscrews. Be sure to recover the 3/8 by 3/16 by 3/32 in. rectangular phenolic "slab" that fits onto the shaft flat, the 1/4-in.-long by 3/8-in. ID metal spacer, the 1-1/16-in. OD by 3/8-in. ID metal spacer, the 1-1/16-in. OD by 3/8-in. ID by 0.01-in. phosphor bronze washer, and the 3/8-in. OD split phenolic sleeve.

e. Remove the RF - AUDIO switch knob and recover the 3/16-in.-long by 3/8-in. ID spacer and the 9/16-in. OD by 3/8-in. ID by 0.01-in. phosphor bronze washer.

f. Remove the RF CONTROL knob after loosening its setscrews, and recover the 3/16-in.-long by 1/4-in. ID spacer and the 1/2-in. OD by 1/4-in. ID by 0.008-in. phosphor bronze washer.

g. Using a long, thin-bladed screwdriver, remove the main tuning dial by loosening the two setscrews at the shaft between the dial and the panel. Recover the 7/8-in. OD by 15/32-in. ID by 0.005-in. phosphor bronze washer and the 3/8-in. ID split phenolic sleeve.

h. Using a Phillips-head screw driver, remove the four bright nickel screws from the front panel near the output jacks and the R-F RANGE SWITCH.

i. At the rear of the instrument, remove the r-f compartment cover by prying it off. It is held quite securely in place by spring pressure.

j. Unplug the Type 874 Connector inside the compartment.

k. Firmly grasping the rear end-plate of the main tuning capacitor, pull the entire r-f unit out of the shielded compartment.

4.3.2 OPERATION WITH R-F SECTION REMOVED FROM COMPARTMENT. To operate the instrument with the r-f unit completely removed from its compartment, remove the two No. 6-32 screws that attach the nine-jack terminal plate to the subpanel. The shaft of the main tuning capacitor goes through this plate. Note how the cable attached to the plate is stored on the subpanel. This jack plate and its cable can be used to connect the r-f section to the corresponding plug plate, which is mounted inside the main instrument.

4.3.3 REPLACEMENT OF R-F SECTION. To reinstall the r-f section in its compartment, proceed as follows:

a. Unplug the nine-pin plug-and-jack assemblies. Carefully wind the two-foot cable about the cable supports and attach the jack plate to the subpanel by means of the two No. 6-32 screws.

b. Replace the r-f section in its shielded compartment. Fasten the unit to the panel by means of the four bright-nickel No. 10-32 screws. The subpanel spacers must bottom properly at the panel and the shafts must not bind at the panel. If there is any tendency to bind, loosen slightly and then retighten the screws (at the panel) that attach the four shaft bearing plates (behind the panel). If the plug-and-jack plates do not seem to line up properly, loosen and then retighten the two screws that attach the plug-plate.

c. Reconnect the Type 874 Connectors inside the r-f section.

d. Make sure all the panel screws are tight.

e. The RF RANGE and main tuning capacitor shafts are metal, and must not be grounded to the outside of the panel, since circulating currents would cause excessive leakage. To prevent this, the

## TYPE 1330-A BRIDGE OSCILLATOR

insulated shaft ends are enclosed by a grounded knob insert or disc hub.

f. To replace the main tuning dial, slip the 3/8-in. ID split phenolic sleeve onto the shaft, put on the 7/8-in. OD by 15/32-in. ID by 0.005-in. phosphor bronze washer and place the dial on the shaft. Replace the plastic index with its two 11/32-in. spacers, two plain washers, two lock washers, and two No. 4-40 screws. Orient the dial so that it indicates at the reference line with the tuning capacitor fully meshed. The accuracy of frequency calibration depends on how carefully this is done. The reference line on the main frequency dial is six degrees below the lowest calibrated frequency mark. To obtain full mesh, butt the rotor plates against a straight-edge held across the stator plates. When everything is properly lined up, press the dial firmly against the panel and tighten the two dial setscrews (between dial and panel), using a long, thin-bladed screwdriver. Make sure that the reference line is indexed for exact full-mesh. If it is not, loosen the index screws and reset the index for exact register. Then retighten the index screws.

g. Attach the dial cover plate, using the two No. 6-32 black-nickled screws. Make sure that the slow-motion dial gear teeth properly engage the teeth of the internal gear on the main dial.

h. The RF RANGE shaft is insulated from the knob insert by a thin phenolic sleeve. A phenolic "slab" at the flat on the shaft insulates the knob's setscrew. A metal spacer and a spring washer complete the shielding and grounding.

i. Set the RF RANGE switch so that the flat of its shaft faces up (toward the 150-500 kc division). Slip the 3/8-in. OD split phenolic sleeve over the shaft, put on the 1-1/16-in. OD by 3/8-in. ID by 0.01-in. phosphor bronze washer and the 1/4-in.-long by 3/8-in. ID brass spacer. Place the 3/8 by 3/16 by 3/32-in. "slab" on the shaft flat and carefully put on the large knob, with the arrow pointing to the 150-500 kc division. Press the knob against the panel and tighten the two setscrews.

j. Replace the 1/4-in. ID washer and the 3/16-in.-long by 1/4-in. ID spacer on the shaft of the RF CONTROL, press the 1/4-in. ID small knob against the panel and tighten the two setscrews, taking care that the knob arrow points in the correct direction.

k. Replace the 9/16-in. OD by 3/8-in. ID by 0.01-in. washer and the 3/16-in.-long by 3/8-in. ID spacer on the RF-AUDIO switch shaft. Press the 3/8-in. ID small knob against the panel and tighten the two setscrews, taking care that the knob arrow points to the correct switch position.

l. Connect power and check that the instrument functions properly.

m. Replace the double-shielded cover, in such a way that the hex wrench is mounted near the bottom of the cabinet.

n. If the instrument is not to be relay-rack mounted, replace it in its cabinet with the 10 No. 10-32 panel screws.

### 4.4 CALIBRATION PROCEDURE.

4.4.1 EQUIPMENT REQUIRED. The following equipment is required to calibrate the Type 1330-A Bridge Oscillator:

Type 1144-A Digital Frequency Meter— a device capable of measuring frequencies of 400 cps, 1 kc and 5 kc to 50 Mc, with an accuracy of 0.3%

An alternate approach to measuring the output frequency of the Type 1330-A directly is to compare it to an accurate ( $\pm 0.3\%$ ) frequency source. The comparison device can be either a mixer with a method of beat detection (earphones, meter, etc.) or an oscilloscope using the Lissajous technique.

Type 1806-A Electronic Voltmeter— or a device capable of measuring 0 to 55  $\Omega$  with an accuracy of  $\pm 20\%$  and 1 to 13 volts rms at 60 cps, 400 cps, 1 kc and 5 kc to 50 mc with an accuracy of  $\pm 3\%$ .

Type 1932-A Distortion and Noise Meter — or a device capable of measuring second- and third-harmonic distortion from 0 to 10% on fundamental frequencies of 400 cps, 1 kc, 8 kc and 15 kc, 1 to 10 volts, rms, with an accuracy of  $\pm 5\%$ .

Oscilloscope capable of observing a 1- to 10-volt rms, 1-Mc signal.

50-ohm termination consisting of a 50- $\Omega$ , 2-watt, non-inductive resistor.

4.4.2 RESISTANCE CHECKS. These resistance measurements need not be made if the unit appears to be operating properly and is being recalibrated during a routine maintenance program and not because of a major failure.

Connect an ohmmeter to the AUDIO output connector and measure the resistance as follows:

RF-AUDIO switch setting	resistance
MOD 1000 C	$\infty$
MOD 400 C	$\infty$
CW	$\infty$
LINE	51 $\Omega$ , $\pm 2.6\Omega$ ( $\pm 5\%$ )
400 C	1 $\Omega$ , approximately
1000 C	1 $\Omega$ , approximately

4.4.3 FREQUENCY.

4.4.3.1 General. Frequency readjustment is necessary to compensate for aging or replacement of the rf tube or its associated circuit components.

For each RF RANGE, the high-frequency end is adjusted first, by means of a trimmer capacitor. The low-frequency end is adjusted next, by means of an adjustable powdered iron core. A screwdriver is required for adjustment of the trimmers. A hex wrench, clipped inside of the rf compartment, is provided for adjustment of the cores.

4.4.3.2 Access to Adjustments. Four holes in the top of the rf compartment (see Figure 3) provide access to most of the cores and trimmers. Except where otherwise noted, the RF RANGE switch must be set to the appropriate range for access to the adjustments.




Figure 3. Locations of Dust Core and Trimmer Adjustments.

4.4.3.3 Audio-Frequency Measurements. Connect the frequency-measuring equipment to the AUDIO output connector and check the frequency as follows:

RF-AUDIO switch setting	check for	tolerance
400 C	400 cps	±20cps (±5%)
1000 C	1000 cps	±50cps (±5%)

4.4.3.4 Radio-Frequency Measurements. Do not terminate the RF connector. Set the RF-AUDIO switch to CW and set the RF CONTROL for a usable output. Connect the frequency-measuring equipment to the RF output connector and check (or adjust, if necessary) the frequency as follows:

RF RANGE	location of adjustment		tolerance
	core	trimmer	
5-15 KC	Rear of instrument, rf compartment cover off	hole B	±3%
15-50 KC	hole A, with RF RANGE switch set to 5-15 KC	hole C	±3%
50-150 KC	hole A	hole B	±3%
150-500 KC	hole D	hole C	±2%
0.5-1.5 MC	hole A	hole B	±2%
1.5-5 MC	hole D	hole C	±2%
5-15 MC	hole A	hole B	±2%
15-50 MC	hole D	hole C	±2%

4.4.4 AMPLITUDE AND DISTORTION. Check the rf amplitude at all frequencies of each RF RANGE setting, first with the output terminated in 50Ω and then with the output unterminated. The amplitude must not dip below the minimum given for each range and the distortion must not exceed the maximum limits, where given.

Use an electronic voltmeter to monitor amplitude and a distortion meter to monitor distortion.

RF AMPLITUDE AND DISTORTION

RF RANGE	minimum amplitude (volts, rms)	maximum distortion (%)
15-50 MC	1.7	—
5-15 MC	2.9	—
1.5-5 MC	6.5	—
0.5-1.5 MC	6.8	—
150-500 KC	6.5	—
50-150 KC	5.5	—
15-50 KC	3.2	7 (at 15 kc)
5-15 KC	2.7	7 (at 8 kc)

AUDIO AMPLITUDE

RF-AUDIO switch setting	amplitude (volts, rms)
LINE	12 to 13, typical
400 C	12 to 13, typical
1000 C	12 to 13, typical

Trouble-shooting notes


Rf amplitude and distortion are determined, in part, by the physical location of the pickoff coils (L102, L202, etc.) in relation to their respective primary coils (L101, L201, etc.).

Do not attempt to solve amplitude or distortion problems by repositioning the pickoff coils, however, without first trouble-shooting the other components in the rf circuit (especially V1) or the power supply (especially V3). This is particularly important if all or several RF RANGES, rather than just one range, exhibit problems. The pickoff coils are positioned at the factory and ordinarily do not require repositioning unless the coil assembly has been replaced. They are cemented in place (except those for the three highest RF RANGES: 15-50, 5-15, and 1.5-5 MC), and repositioning usually requires removal of the entire rf section (see paragraph 4.3.1).

4.4.5 DISTORTION AND PERCENT MODULATION. The percent modulation can be determined by the following equation:

TYPE 1330-A BRIDGE OSCILLATOR

$$\% \text{ modulation} = \frac{A-B}{A+B} \times 100$$



If A = 4 divisions of oscilloscope deflection, then:

- B = 2.4 divisions for 25% modulation
- B = 1.33 divisions for 50% modulation

To measure percent modulation, set the RF RANGE switch to 0.5-1.5 MC and set the frequency control for 1 Mc. Use an oscilloscope to monitor percent modulation and a distortion meter to monitor distortion as follows:

RF AUDIO switch setting	% MOD switch setting	approximate modulation	maximum distortion
MOD 400 C	LOW	25%	4%
MOD 400 C	HIGH	50%	6%
MOD 1000 C	HIGH	50%	6%
MOD 1000 C	LOW	25%	4%

4.5 TEST VOLTAGES. The Table of Voltages (below) lists test voltages at tube socket pins as an aid in trouble-shooting. Voltages, d-c to ground except as otherwise noted, were measured with a 20,000-ohm-per-volt multimeter with full-scale ranges of 10, 50, 250, and 1000 volts. Variations of up to ±20% should not be considered abnormal for d-c voltages. Switch settings for the test voltages are:

- RF - AUDIO at 400c MOD
- frequency at 1 Mc
- % MOD at LOW
- RF CONTROL fully counterclockwise
- input voltage: 115 volts, 60 cycles

TABLE OF VOLTAGES


TUBE (TYPE)	PIN	VOLTS	TUBE (TYPE)	PIN	VOLTS	TUBE (TYPE)	PIN	VOLTS
V1 (6AQ5)	1	-21.5	V2 (6AQ5)	1	-9.3	V3 (6X4)	1	285 ac
	2	3.5		2	7.3		3	6.1ac
	3	0		3	5.9ac		4	0
	4	5.9ac		4	11.9ac		6	285 ac
	5	225		5	180		7	310
	6	157		6	180			
	7	-21.5		7	-9.3			

## PARTS LIST


	REF DES	GR NO. (NOTE A)	REF DES	GR NO. (NOTE A)	
RESISTORS (NOTE B)	R1	47 k ±10% 1/2w 6100-3475	C101	7-45µf 4910-0100	
	R2	15 k ±10% 1w 6110-3159	C201	7-45µf 4910-0100	
	R3	18 k ±10% 1w 6110-3189	C301	7-45µf 4910-0100	
	R4	6.8 k ±10% 2w 6120-2689	C401	7-45µf 4910-0100	
	R5	18 k ±10% 2w 6120-3189	C501	7-45µf 4910-0100	
	R6	27 k ±10% 1w 6110-3279	C601	7-45µf 4910-0100	
	R7	470 ± 5% 1/2w 6100-1475	C701	7-45µf 4910-0100	
	R8	330 ±10% 1/2w 6100-1335	C801	7-45µf 4910-0100	
	R9	51 ± 5% 2w 6120-0515			
	R10	250 ±10% 6020-0100			
	R12	220 ± 5% 1/2w 6100-1225	F1	FUSE, 0.5 amp Slo-Blo Type 3AG (for 115v) 5330-1000	
	R13	390 ±10% 1/2w 6100-1395			
	R14	18 k ±10% 2w 6120-3189	F1	FUSE, 0.25 amp Slo-Blo Type 3AG (for 230v) 5330-0700	
	R15	22 k ±10% 2w 6120-3229			
	R16	3.3 k ±10% 2w 6120-2339	F2	FUSE, 0.5 amp Slo-Blo Type 3AG (for 115v) 5330-1000	
	R17	1 ±10% 1w 6760-9109			
	R19	560 ±10% 2w 6120-1569	F2	FUSE, 0.25 amp Slo-Blo Type 3AG (for 230v) 5330-0700	
	R20	560 ±10% 2w 6120-1569			
	R21	620 ± 5% 2w 6120-1625			
	R22	15 ±10% 1/2w 7510-1930			
		R101	750 ± 5% 1w 6110-1755		
		R102	75 k ± 5% 2w 6120-3755		
	R201	47 k ±10% 2w 6120-3479			
	R202	47 k ±10% 2w 6120-3479			
CAPACITORS (NOTE C)	C1	820 µf 0848-4042	MISCELLANEOUS	L101	INDUCTOR 1330-0280
	C2	35 µf ± 5% 4660-1500		L102	INDUCTOR 1330-0280
	C3	0.22 ± 5% 4514-4255		L201	INDUCTOR 1330-0290
	C4	0.47 ±20% 4512-4479		L202	INDUCTOR 1330-0290
	C5	0.002 +30%-10% 4920-2500		L301	INDUCTOR 1330-2010
	C6	0.02 ±10% 4510-2400		L302	INDUCTOR 1330-2010
	C7	0.05 ±10% 4510-2000		L401	INDUCTOR 1330-2020
	C8	0.25 ± 5% 4510-3600		L402	INDUCTOR 1330-2020
	C9	20 450dcwv 4450-0300		L501	INDUCTOR 1330-2030
	C10	0.47 ±20% 4514-4479		L502	INDUCTOR 1330-2030
	C11	0.47 ±20% 4514-4479		L601	INDUCTOR 1330-2040
	C12	20 } 450dcwv 4460-0900		L602	INDUCTOR 1330-2050
	C13	20 } 4460-0900		L701	INDUCTOR 1330-2060
	C14	20 } 4460-0900		L702	INDUCTOR 1330-2070
	C15	20 } 4460-0900		L801	INDUCTOR 1330-0270
	C16	0.01 ±10% 4760-0100		L802	INDUCTOR 1330-2080
	C17	0.01 ±10% 4760-0100		L803	INDUCTOR, 0.47µH±15% 4300-0400
	C18	0.0022µf ±10% 400dcwv 4863-3229		P1	LAMP, 6.3v Mazda 44 5600-0700
		S1	SWITCH, 8 pos. 1330-0370		
		S2	SWITCH 7890-0550		
		S3	SWITCH, dpst 7910-1300		
		S4	SWITCH, dpdt 7910-1500		
		T1	TRANSFORMER 0345-4540		
		T2	TRANSFORMER 0485-4650		

All resistances are in ohms except as otherwise indicated by k (kilohms).

All capacitances are in microfarads, except as otherwise indicated by µf (micromicrofarads).



Elementary Schematic Diagram



Tube Layout-Rear View

Rotary switch sections are shown as viewed from the panel end of the shaft. The first digit of the contact number refers to the section. The section nearest the panel is 1, the next section back is 2, etc. The next two digits refer to the contact. Contact 01 is the first position clockwise from a strut screw (usually the screw above the locating key), and the other contacts are numbered sequentially (02, 03, 04, etc), proceeding clockwise around the section. A suffix F or R indicates that the contact is on the front or rear of the section, respectively.




Figure 4. Schematic Diagram.

# GR874 COAXIAL COMPONENTS

GR874 CABLE CONNECTORS									
		CONNECTOR TYPE	CABLE	CABLE LOCKING	PANEL FLANGED	PANEL LOCKING	PANEL LOCKING RECESSED	PANEL LOCKING (KEYED)	
		APPLICABLE CABLE TYPES	50-OHM	874-A2	-CA	-CLA	-PBA	-PLA	-PRLA
RG-8A/U RG-9B/U RG-10A/U RG-87A/U RG-116/U RG-156/U RG-165/U RG-166/U RG-213/U RG-214/U RG-215/U RG-225/U RG-227/U									
NON-50-OHM	RG-11A/U RG-12A/U RG-13A/U RG-63B/U RG-79B/U RG-89/U RG-144/U RG-146/U RG-149/U RG-216/U								
	874-A3			-CSA	-CL58A	-PB58A	-PL58A	-PRL58A	-PBL58A
	RG-29/U RG-55/U (Series) RG-58/U (Series) RG-141A/U RG-142A/U RG-159/U RG-223/U								
	RG-59/U RG-62/U (Series) RG-71B/U RG-140/U RG-210/U								
50-OHM	RG-174/U RG-188/U RG-316/U RG-161/U RG-187/U RG-179/U		-C174A	-CL174A	-PB174A	-PL174A	-PRL174A	-PBL174A	

Example: For a locking cable connector for RG-8A/U, order Type 874-CL8A.

GR874 ADAPTORS		
TO TYPE		TYPE 874
APC-7		QAP7L*
BNC	plug	QBJA QBJL*
	jack	QBPA
C	plug	QCJA QCJL*
	jack	QCP
GR900		Q900L*
HN	plug	QHJA
	jack	QHPA
LC	plug	QLJA QLPA
	jack	
LT	plug	QLPT
	jack	QLTJ
Microdot	plug	QMDJ QMDJL*
	jack	QMDP
N	plug	QNJA QNJL*
	jack	QNP QNPL*
**OSM/BRM	plug	QMMJ QMMJL*
	jack	Q MMP QMMPL*
SC (Sandia)	plug	QSCJ
	jack	QSCJL* QSCP
TNC	plug	QTNJ QTNJL*
	jack	QTNP
UHF	plug	QUJ QUJL*
	jack	QUP
UHF 50-Ω Air Line	7/8-in.	QU1A
	1-5/8-in.	QU2
	3-1/8-in.	QU3A

\*Locking GR874 Connector  
Example: To connect Type 874 to a type-N jack, order Type 874-QNP

\*\*Reg. T.M. Omni Spectra, Inc.

OTHER COAXIAL ELEMENTS			
TYPE 874	DESCRIPTION	TYPE 874	DESCRIPTION
A2	50-Ω cable (low loss)	MB	coupling mount
A3	50-Ω cable	MR, MRL, MRAL	mixer-rectifier
D20L, D50L	20-, 50-cm adjustable stubs	R20A, R20LA	patch cord, double shield
EL, EL-L	90° ell	R22A, R22LA	patch cord, double shield
F185L	185-MHz low-pass filter	R33, R34	patch cord, single shield
F500L	500-MHz low-pass filter	T, TL	tee
F1000L	1000-MHz low-pass filter	TPD, TPD L	power divider
F2000L	2000-MHz low-pass filter	U	U-line section
F4000L	4000-MHz low-pass filter	UBL	bahun
FBL	bias insertion unit	VCL	variable capacitor
G3, G3L, G6, G6L	3-, 6-, 10-, 14-, and 20-dB attenuators	V1	voltmeter indicator
G10, G10L, G14, G14L		VQ, VQL	voltmeter detector
G20, G20L		VR, VRL	voltmeter rectifier
GAL		W100	100-Ω termination
JR	adjustable attenuator	W200	200-Ω termination
K, KL	rotary joint	W50B, W50BL	50-Ω termination
L10, L10L	coupling capacitor	WN, WN3, WNL	short-circuit terminations
L20, L20L	10-, 20-, and 30-cm rigid air lines	WO, WO3, WOL	open-circuit terminations
L30, L30L		X	insertion unit
LAL	35-58 cm adjustable line	XL	series inductor
LK10L, LK20L	constant-Z adjustable lines	Y	cliplock
LR	radiating line	Z	stand
LTL	trombone constant-Z line	-9508	air line inner conductor
ML	component mount	-9509	air line outer conductor

CONNECTOR ASSEMBLY TOOLS	
TYPE 874	FUNCTION
TOK	Tool Kit
TO58	Crimping Tool
TO8	Crimping Tool

MISCELLANEOUS COAXIAL CONNECTORS		
CONNECTOR TYPE	TYPE NO.	USED WITH
Basic	874-B	50-ohm air line
Basic Locking	874-BBL	50-ohm air line
Panel Locking	874-PLT	Wire lead
Panel Locking Recessed	874-PRLT	Wire lead
Panel Locking Feedthrough	874-PFL	Type 874 patch cords

L suffix indicates locking Type 874 Connector.

# GENERAL RADIO COMPANY

WEST CONCORD, MASSACHUSETTS 01781

617 369-4400

617 646-7400

## DISTRICT OFFICES

### METROPOLITAN NEW YORK \*

845 Broad Avenue  
Ridgefield, New Jersey 07657  
Telephone N.Y. 212 964-2722  
N.J. 201 943-3140

### SYRACUSE

Pickard Building  
East Molloy Road  
Syracuse, New York 13211  
Telephone 315 454-9323

### NEW ENGLAND \*

22 Baker Avenue  
West Concord, Massachusetts 01781  
Telephone 617 646-0550

### PHILADELPHIA

Fort Washington Industrial Park  
Fort Washington, Pennsylvania 19034  
Telephone 215 646-8030

### WASHINGTON \* AND BALTIMORE

11420 Rockville Pike  
Rockville, Maryland 20852  
Telephone 301 946-1600

### ORLANDO

113 East Colonial Drive  
Orlando, Florida 32801  
Telephone 305 425-4671

\* Repair services are available  
at these district offices.

### CHICAGO \*

9440 W. Foster Avenue  
Chicago, Illinois 60656  
312 992-0800

### CLEVELAND

5579 Pearl Road  
Cleveland, Ohio 44129  
Telephone 216 886-0150

### LOS ANGELES \*

1000 North Seward Street  
Los Angeles, California 90038  
Telephone 213 469-6201

### SAN FRANCISCO

626 San Antonio Road  
Mountain View, California 94040  
Telephone 415 948-8233

### DALLAS \*

2600 Stemmons Freeway, Suite 210  
Dallas, Texas 75207  
Telephone 214 637-2240

### TORONTO \*

99 Floral Parkway  
Toronto 15, Ontario, Canada  
Telephone 416 247-2171

### MONTREAL

1255 Laird Boulevard  
Town of Mount Royal, Quebec, Canada  
Telephone 514 737-3673

OTTAWA Telephone 613 233-4237

General Radio Company (Overseas), 8008 Zurich, Switzerland  
General Radio Company (U.K.) Limited, Bourne End, Buckinghamshire, England  
Representatives in Principal Overseas Countries

Printed in USA